

SWITCH REPLACEMENT

Switch Replacement Instructions for Sidewinder® Tube Skimmers

REPLACEMENT INSTRUCTIONS:

- 1) Unplug the unit from any power source.
WARNING! Switch should not be worked on with the unit plugged into any power source. The risk of electrical shock exists.
- 2) Remove the top of the unit by removing two (2) black screws.
- 3) Locate three (3) prong switch connections (A) as noted in (Figure 1). Disconnect using needle nose pliers.
- 4) **REMOVE FAILED SWITCH BY PRYING LOCKING TABS AWAY. PLEASE NOTE THE ORIENTATION OF THE CONNECTIONS ON THE OLD SWITCH.**
- 5) Install new switch with connections oriented the following way.
 - a) The silver connector will be the closest to the motor (white wire).
 - b) Connect motor wire next to copper connector.
 - c) The final connection is the Powerline cord to be connected to the gold tab.
 - d) Insert switch back into metal case and lock in place with tabs.
- 6) Plug the unit into a power supply and verify the switch is working. Once confirmed, reassemble unit by replacing the cover and screws.




Figure 1

For any technical questions
or product support, please
contact us at 888.249.4855



Zebra Skimmers Corporation

27000 Richmond Road #1 | Solon, OH 44139 | Toll Free: 888.249.4855 | Fax: 440-349-1211
sales@zebraskimmers.com | www.zebraskimmers.com